

How to Measure & Order Columbia Storm Doors


Opening size should be taken of the door frame from outside of the entrance.

WIDTH:

Measure the opening near the top, middle and near the bottom. Use the smallest measurement to order the door (A, B & C).




HEIGHT:

Measure the height from the threshold to the header (both sides of door). Use the smallest measurement to order the door.



HINGE LOCATION:

Face your door opening from outside the house. If hinges are needed on the left side, specify a left hinge door. If hinges are needed on the right, specify a right hinge door.



STANDARD DOOR SIZES

2 ⁶ x 6 ⁸	30" x 81"
2 ⁸ x 6 ⁸	32" x 81"
3 ⁰ x 6 ⁸	36" x 81"

Fits Opening Width

29 7/8" x 30 1/8"
31 7/8" x 32 1/8"
35 7/8" x 36 1/8"

Fits Opening Height

79 1/2" x 81"
79 1/2" x 81"
79 1/2" x 81"


Opening Size

_____ X _____

_____ X _____

_____ X _____

Distributed by



Columbia

Windows & Doors

1600 N. Jackson • Kansas City, MO
816-241-5800 • Toll Free 1-800-892-8703

Lindsborg, KS
785-227-3087
1-800-255-0174

Iola, KS
316-365-3166
1-800-362-0503

Pawnee, OK
918-762-3001
1-800-722-4144